

USER MANUAL

Escalator Cleaning Machine



Introduction

Automatic step ladder cleaning machine for cleaning a variety of different escalators, lightweight, folded display, convenient transportation. The machine is equipped with stain brush and a dust collecting device, collector, wiping, cleaning functions, convenience, simple operation. The automatic step ladder cleaning machine is placed in the step ladder run on clean, normally only needs 15 minutes to complete the automatic step ladder cleaning easy, step ladder to restore clean and bright.

- Automatically lifting cleaner is fit to clean all kinds of escalators.
- Its weight is light. It can be fold and is easy to transport.
- The machine with two rolling brushes which are used to collecting the dirties and the dust catching equipment with big power has special effect to eliminate the hard dirt for everyday cleaning and upholding.
- Double system inside to filtrate the small dust.
- There is an equipment to prevent the sound, is valid to reduce the noise.
- In the normal state, you only put the machine on the moving escalator and then it can clean the escalator automatically.
- The whole process only needs no more than 15 minutes.

Using steps:

1. The correct installation of dust bag.
2. The host is placed in the automatic step ladder, pull the armrest.
3. In the automatic step ladder on the other side placed noted on the label.
4. Connect the power.
5. Turn on the switch, the host operation.

Matters needing attention:

Caution: Moving escalator cleaner must be cleaned upon the staircase while moving escalator operates upgrade. Moving escalator cleaner must be cleaned down the staircase while moving escalator operates downgrade.

Escalator cleaner machine technical parameters

Item No: LP-460

Working Width: 45cm

Power: 2000W

Volume: 20L

Cable: 15M

Voltage: 220V-240V/50HZ

Weight: 35KG

Safe Standards: level 1

Noise : ≤ 60 dba