

# 7.5 inch Red E-paper Signage GDU075R1



Dalian Good Display Co., Ltd.



# **Product Specifications**



Customer	Standard		
Description	E-paper Signage		
Model Name	GDU075R1		
Date	2023/11/21		
Revision	1.0		

Design Engineering			
Approval	Check	Design	
宝刘 印玉	燕修 印凤	之印	

Zhongnan Building, No.18, Zhonghua West ST, Ganjingzi DST, Dalian, CHINA

Tel: +86-411-84619565

Email: info@good-display.com

Website: www.good-display.com



# Contents

1.	Overview	4
2.	Product Advantages	4
3.	Mechanical Specifications	5
4.	Product Structure	5
5.	Display Updates	6
6.	Packaging and Installation	9

#### 1. Overview

The GDU075R1 electronic paper display board utilizes the traditional USB communication method. Additionally, it is equipped with host software, allowing users to directly update the current display on a PC through this software. This design simplifies the updating process, eliminating the need for users to engage in modeling operations; they only need to import the images they wish to display into the software. Through USB communication and host software, users can achieve real -time updates to the content on the electronic paper display board. This functionality is highly useful for scenarios requiring frequent changes in display content or real-time information updates. By employing this communication method, user operation becomes more convenient, requiring no specialized skills; even ordinary users can effortlessly update and control the display content. This display board fully leverages the bistable nature of electronic paper, eliminating the need for an internal battery, ensuring the displayed images remain stable for extended periods.

### 2. Product Advantages 2.1. Basic Functions

Refresh Modes: Full update for 26s, fast update for 16s Display Direction: Horizontal and vertical Drawing Method: Dot matrix Driving Method: USB direct drive

#### 2.2. Basic Parameters

Product Size: 7.5 inch Resolution: 800x480 Color: Black, white and red Operating Temperature: 0~40 °C

#### 2.3. Main features

Display Characteristics: Bistable Electrophoretic Display Technology Display Mode: Pure reflection Viewing Angle: Wide viewing angle, greater than 170 degrees Surface Treatment: Hard-coated anti-glare treatment Environmentally Friendly and Low Carbon: No update, no power consumption Eye Protection: No blue light, no radiation

#### **2.4. Product Applications**

Libraries, museums, hospitals, government institutions, supermarkets, etc.

# 3. Structure Specification

Model	GDU075R1
Selectable Operating Systems	Windows
Outline Size	196x138x12mm
Power Supply	USB-powered
Operating Temp.	0 °C ~ 40 °C
Main Function	USB Communication
Motherboard Specifications	MCU: STM32F1 series Interface: USB supported Image rotation: Manual rotation at 0/90/180/270 degrees

# 4. Product Structure



Figure 1 : Front view of GDU075R1





Figure 2 : Side view of GDU075R1

 Micro USB port Insert the Micro USB.

## 5. Display Updates

#### **5.1 Picture Requirements**

Formats: BMP and JPG Resolution: Screen supports a resolution of 800x480.

Utilize the ImageToEsl.exe tool to import the images.

# 5.2 Serial Port Configuration

1. Install CH340 Serial Port Driver

Double-click on the CH340 driver SETUP.EXE file, then click "Install." After the driver installation, click "OK" to confirm.



2. Open the tool (ImageToEsl.exe) software, select the corresponding port. When the software opens normally, the information bar will display the available serial port number(s) of the current computer. Simply choose the port number that corresponds to yours and use the "Clear" button to update



the currently displayed port number(s).

Data Transm	ission
<u> </u>	connect

3. Click on "connect" to establish the serial port connection. The information bar will display "connect is success!", indicating a successful serial port connection.

COM5 👻	connect
	Display

## **5.3 Displaying Images**

1. Click the "Open File" button and select the prepared image. Once the image is imported, the software will prompt and display the image's dimensions, resolution, color depth, and other parameters.

MageToEsl v3.0	1 Contraction	1000	_		
Load image and display				1	Data Transmission
Open File	Thr	ree Colo	r		COM5 - connect
					Display
				17	
	19	2.17	1	$\tilde{\mathbf{r}}$	COM5 with=800
		). [/	-		7.5 inch
				SPECIAL US	
and the second sec	<b>₩</b> 07:10	🔆 17:00	<b>§</b> 5℃	0 55%	
SAT.	TODAY	SUN.	MON.	TUES.	
TEMD (%)	1/8	1/9	1/10	1/11	
5 A	SUNNY		SNOW/	ΡΔΙΝ	
4 /	NI/	CLOODI	511011		
	-O-	B	6	63	
	A.	_	*	14	
19 00 06 12 18	F/3-4	<b>《</b> /3-4	F/3-4	∧/3-4	
			1 • • • • • •	17.11.	
💡 DALIAN 🕻 🗔	MEMO :	125 DAYS B	EFORE BI	RTHDAY	
About				180 † ↓	Clear

2. Click on "Display". Under normal data transmission conditions, the left-hand information bar will show "Successful handshake," indicating a successful serial port handshake. Simultaneously, it will display the current data transmission progress and the amount of data being transferred.



# **5.4 Frequently Asked Questions**

1. Serial Port Connection Abnormalities:

1) Unable to locate serial port: Possible reasons include the absence of installed serial port drivers, issues with the data cable, or the power switch of the DEMO board not being turned on.

2) Data transmission failure: Check if the serial port is properly connected. If there is an interruption in the serial port connection, kindly try unplugging and re-plugging the serial port cable and then restart the software.

2. Data communication failure:

When the serial port connection is established, after importing an image and clicking 'Display,' if there's no successful handshake information displayed in the left-hand information panel, you can disconnect the 'connect' option. Click on the 'Clear' button to refresh and re-identify the serial port. Select the appropriate serial port number and reconnect to initiate data transmission again.

### 6. Packaging and Installation

# 6.1 Please verify if you have received the following items containing the package contents:

- E-paper Display
- USB Data Cable



# **6.2 Product Installation**

• The product should be installed on a flat surface to prevent potential tipping over.

Leave adequate space between the back of the product and the wall to ensure proper ventilation. Avoid installing the product in kitchens, bathrooms, or areas exposed to high humidity as it may shorten the product's lifespan.

• Do not install the product at altitudes above 3000 meters, as it may result in malfunction.